

Meat&Doria **13201**
Hoffer Products **H13201**



FOCUS LPG injectors

What they are

LPG injectors are components specifically designed to work with a variety of engines **equipped with Landi gas systems.**

Installed on rails, they deliver gas **directly into the intake ports** and are used in dual fuel systems that feature direct gas injection.

Benefits of LPG injectors

Versatility

They are compatible with original equipment gas systems.

Ease of Installation

No modifications to the vehicle's original system are needed.

Adjustment

They enable the optimization of gas delivery, enhancing both performance and fuel efficiency.

Cost Savings

Easy fit

Quick injector replacement using the original vehicle structure.



Important notes

When selecting an injector, it's crucial to check the **color** and **connection type** of the system, as these details correspond to the emission standards listed in the vehicle's registration document (point V9), indicating the **Euro 4 - Euro 5** classification.

Meat&Doria **13201**
Hoffer Products **H13201**

Euro regulation : **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13202**
Hoffer Products **H13202**

Euro regulation: **5**
Connection type: **oval**
Cap color: ●



Meat&Doria **13203**
Hoffer Products **H13203**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13204**
Hoffer Products **H13204**

Euro regulation: **5**
Connection type: **oval**
Cap color: ●



Meat&Doria **13205**
Hoffer Products **H13205**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13206**
Hoffer Products **H13206**

Euro regulation: **5**
Connection type: **oval**
Cap color: ●



Meat&Doria **13207**
Hoffer Products **H13207**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13208**
Hoffer Products **H13208**

Euro regulation: **5**
Connection type: **oval**
Cap color: ●



Meat&Doria **13209**
Hoffer Products **H13209**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13210**
Hoffer Products **H13210**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ○



Meat&Doria **13211**
Hoffer Products **H13211**

Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13212**
Hoffer Products **H13212**


Euro regulation: **4**
Connection type: **rectangular**
Cap color: ●



Meat&Doria **13201**
Hoffer Products **H13201**



Bench assembly instructions



FOCUS
LPG injectors



Focus n. 011
November 2024


MEAT & DORIA
SPECIAL PARTS
SINCE 1945

HOFFER
PRODUCTS
SINCE 1999

Bench assembly instructions

Removal of original injectors

- 1 Remove the rail from the vehicle



- 2 Unscrew the 4 bolts, remove the ring, and extract the original injectors



- 3 The original rail is ready to accommodate the MEAT&DORIA injectors



The assembly

Installation of MEAT&DORIA injectors

- 1 Lubricate directly the two O-rings of the MEAT&DORIA injector without obstructing the gas inlet and outlet holes




- 2 Insert the 4 MEAT&DORIA injectors fully until you hear a "Click"



Bench assembly instructions

3 After the 'Click', the 4 MEAT&DORIA injectors must be installed as shown in the picture



4 Apply the 4 spacers included in the kit, reposition the original bracket, and re-tighten the 4 bolts



5 MEAT&DORIA gas injectors: **installation completed!**



Note


Once the MEAT&DORIA injectors are installed, replace the gas filters before handing over the vehicle.




Meat&Doria **13201**
Hoffer Products **H13201**



Assembly instructions on the vehicle without removing the rails



Assembly instructions on the vehicle without removing the rails



If the rail is mounted above the engine, simply open the hood and replace the original injectors with the new MEAT&DORIA injectors.

If the rail is mounted beneath the engine, lift the vehicle on a hoist and proceed as shown in the example below.


Removal of original injectors

On a 2014 Lancia Y Euro 6 with a 1200 engine as an example. For other vehicles, there may be variations.

- 1 Lift the vehicle on the hydraulic lift




- 3 Remove the original injectors (see the other page if necessary)



- 2 Remove bracket "A" to expose rail "B" with the original injectors. In some cases, you may need to move the engine forward to make it easier to remove/install the injectors



- 4 Insert the new MEAT&DORIA injectors (see the other page)




Assembly instructions on the vehicle without removing the rails



- 5 Remove the hard plastic cover from the original connectors



- 3 Connect the connectors to the new MEAT&DORIA injectors



Note

Once the MEAT&DORIA injectors are installed, replace the gas filters before handing over the vehicle.

Placement on vehicle

